



### Equipment Needed

- Clear plastic sheeting to cover a windscreen and side windows etc.  
(This can be purchased from either a carpet shop or builders merchants or suppliers on the internet. We can supply the kit at a cost of £5, which will be refunded if you proceed with an order.)
- A thick permanent marker pen
- Scissors or a Stanley knife
- Masking Tape, Sellotape or other suitable tape

### Instructions

- 1** Tape the plastic sheeting over the outside of the window.
- 2** With the marker pen, draw round the inside of the rubber beading of the window.
- 3** Take the sheeting down and cut away the excess plastic but do not cut into the boundary of the pattern.
- 4** Don't forget to allow for the mirror in the centre of the windscreen, or other obstructions. Indicate the position of the mirror, on the front windscreen pattern.
- 5** Once this is done you should have a piece of plastic that is the same size as the visible glass.
- 6** Now try fitting the pattern on the inside of the window. Sometimes the dashboard comes further up the windscreen on the inside of the cab, therefore this is important. You will have to make an adjustment on the pattern if this is the case.
- 7** Repeat the procedure for all other windows required.
- 8** If you have a digital camera, it would assist us if you could photograph the cab section.
- 9** E-mail or post the photographs with the finished pattern to us. It may help in highlighting possible problems before the screens are manufactured.

After receipt of your template, we will offer you a price to manufacture your screens.

If you require further help and advice please contact us. Turn-around is approximately 4 weeks.

### Important

Please indicate on both faces of each screen pattern, whether it is facing the inside or outside. Where a vehicle has different passenger and driver side windows, this is very important.